



Modell	A1	A2	X1	X2	Y1	Y2	B1	B2	C1	C2	D	H
<b>KDD 80Lx80R</b>	800	800	792-802	792-802	773-783	773-783	485	485	270-280	270-280	690	1950
<b>KDD 80Lx90R</b>	800	900	792-802	892-902	773-783	873-883	485	585	270-280	270-280	760	1950
<b>KDD 80Lx100R</b>	800	1000	792-802	992-1002	773-783	973-983	485	685	270-280	270-280	830	1950
<b>KDD 90Lx80R</b>	900	800	892-902	792-802	873-883	773-783	585	485	270-280	270-280	760	1950
<b>KDD 90Lx90R</b>	900	900	892-902	892-902	873-883	873-883	585	585	270-280	270-280	830	1950
<b>KDD 90Lx100R</b>	900	1000	892-902	992-1002	873-883	973-983	585	685	270-280	270-280	900	1950
<b>KDD 100Lx80R</b>	1000	800	992-1002	792-802	973-983	773-783	685	485	270-280	270-280	830	1950
<b>KDD 100Lx90R</b>	1000	900	992-1002	892-902	973-983	873-883	685	585	270-280	270-280	900	1950
<b>KDD 100Lx100R</b>	1000	1000	992-1002	992-1002	973-983	973-983	685	685	270-280	270-280	970	1950